

# CTC EcoHeat 300

## Kompressorval

**SV**

Starta maskinen. Kompressortyp måste nu ställas in under "Avancerat/Service/Kodade inställningar/Kompressordrift". Kod 3991.

Kompressorbenämning	Värmepump
AEH33YEYMY	CTC EcoHeat 306, 6 kW
ZH21K4E-TFD	CTC EcoHeat 308, 8 kW
ZH26K4E-TFD	CTC EcoHeat 310, 10 kW
ZH30K4E-TFD	CTC EcoHeat 312, 12 kW



## Selection of compressor

**EN**

Start the machine. Compressor type must now be set under "Advanced / Service / Coded settings / Compressor Operation". Code 3991.

Compressor Name	Heatpump
AEH33YEYMY	CTC EcoHeat 306, 6 kW
ZH21K4E-TFD	CTC EcoHeat 308, 8 kW
ZH26K4E-TFD	CTC EcoHeat 310, 10 kW
ZH30K4E-TFD	CTC EcoHeat 312, 12 kW

